



Oil Sample Instructions

Thank you for choosing Savant Labs to analyze your samples. We want to ensure that your sampling project results provide reliable, repeatable and meaningful data. Sample integrity is a very important component to achieving reliable data. Another component is working with a quality lab; by choosing Savant you have selected a lab in the lubricant testing business with a reputation for reliability and quality for over forty years. Below are instructions for shipping your sample for testing.

Sample Bottles:

- 1) Bottle oil sample with enough sample to complete all testing requested.
- 2) Fill a suitable bottle with oil sample.
- 3) Cap sample bottle(s).
- 4) Place a label with your information filled out on the sample bottle(s).
- 5) Place tape around the cap of each sample bottle, this will help with the cap from becoming loose during shipping.
- 6) Place clear tape over the sample information label, this will ensure your information does not get compromised if any of the sample does leak out of the bottle.
- 7) Place individual sample(s) in plastic bags
- 8) Place sample(s) and a SDS sheet in a box with Savant's address label.
- 9) Ship samples to Savant.

Savant Labs

4800 James Savage Road

Midland, MI 48642

- 10) When samples are shipped please send an email to savant@savantgroup.com, with the number of samples and when Savant can expect to receive them.